

POWERFLEX®

PART NUMBER

PFF76-1001

DESCRIPTION

FRONT WISHBONE FRONT BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane A Bushes
- 1 x PTFE/Silicone Grease
- 2 x Polyurethane B Bushes
- 2 x Stainless Steel Sleeves
- 2 x Steel Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the wishbones from the vehicle
2. Using a press and suitable adaptors, press the original bush out of the wishbone.
3. Clean the bore of the arm and remove any burrs, sharp edges or corrosion.
4. Push the shorter bush (marked PFF76-1001) into the front end of the mounting bore, and the longer bush (marked PFF12-701) into the rear end.
5. Liberally apply the supplied grease to the knurled bore of the bush and the end faces, and push the stainless steel sleeve into the bush.
6. Place the steel washers on the front end of the bush, using some grease to hold it in place whilst mounting.
7. Refit the wishbone to the vehicle, ensuring to tension all fasteners to the manufacturers' recommended torque settings.

