



PART NUMBER

PFF76-1002

DESCRIPTION

FRONT WISHBONE REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane A Bushes
- 1 x PTFE/Silicone Grease
- 2 x Aluminium Outer Shells
- 2 x Stainless Steel Sleeves
- 4 x Nylon Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the wishbones from the vehicle
2. Using a press and suitable adaptors, press the original bush out of the wishbone.
3. Press the black anodised aluminium shell into the arm from the top face.
4. Using washing up liquid as a lubricant, press the polyurethane bush into the shell, with the smaller diameter facing downwards.
5. Liberally apply the supplied grease to the knurled bore of the bush and the top faces, and push the stainless steel sleeve into the tapered bore of the bush, leaving an equal amount protruding from each end.
6. Place the nylon washers on each end of the bush, around the stainless steel sleeve.
7. Refit the wishbone to the vehicle, ensuring to tension all fasteners to the manufacturers' recommended torque settings.

