



PART NUMBER

PFF85-1923

DESCRIPTION

LOWER TORQUE MOUNT LARGE BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 1 x Polyurethane Bush
- 1 x Stainless Steel Sleeve
- 1 x Zinc Plated Mild Steel Shell

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the lower torque mount from the vehicle.
2. Using a workshop press and appropriately sized tubes, press the original voided rubber bush out of the mount.
3. Press the new zinc-plated outer shell into the bracket, using the lead-in to guide the shell into the bore straight. Press until flush with both sides of the bracket.
4. Lubricate the bush with dish soap and push into the shell using the press or a vice.
5. Push the sleeve into the bush.
6. Refit the mount to the car, ensuring to tighten all hardware to manufacturers recommended torque settings.

