

INSTALLATION GUIDE

Contents (parts per pack):

4 x Polyurethane bushes	2 x Outer steel shells
2 x Stainless steel sleeve	1 x Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original bush from the arm.
 2. Clean any dirt and corrosion from the bore in the arm. Remove any sharp edges from the bore of the arm.
 3. Press shell into bore of the arm with smaller diameter leading to ease insertion.
- Note: The side of insertion into the arm bore does not affect performance.*
4. Insert polyurethane bushes into bore of the shell.
 5. Apply grease into bore of the bush and around top faces.
 6. Fit sleeve into bush.
 7. Re-fit arm to the car. Tension all hardware to manufacturers recommended torque settings.

