

POWERFLEX®

PART NUMBER

PFF80-1501

DESCRIPTION

FRONT ARM FRONT BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane A Bushes 1 x PTFE/Silicone Grease
2 x Polyurethane B Bushes 2 x Stainless Steel Sleeves

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original rubber bush from the front arm front position.
2. Clean any dirt and corrosion from the bore of the arm and file off any sharp edges.
3. Insert polyurethane part A into the bore of the front arm so that the lip faces towards the front of the car, as shown in Figure 1.
4. Insert polyurethane part B into the bore so that the lip faces towards the rear of the car, as shown in Figure 1.
5. Apply some of the supplied grease into the bore of the polyurethane bush and push in the stainless steel sleeve so that it sits flush inside the bush.
6. Refit the arm back to the vehicle and tension all hardware to manufacturers recommended torque settings.

