

# POWERFLEX®

## PART NUMBER

# PFF88-1130

## DESCRIPTION

## LOWER ENGINE MOUNT INSERT

## INSTALLATION GUIDE

### Contents (parts per pack):

1 x Polyurethane Bush 1 x M12 Plated Washer

1 x Zinc Plated Mild Steel Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

### Fitting Instructions:

1. Remove the original mount, ensuring to retain all original hardware.
2. Insert the Polyurethane Bush into the voids of the original bush, until the bush sits flush.
3. Place the large Zinc Plated Mild Steel Washer onto the flat face of the bush, and refit the original bolt through the bore of the bush.
4. Place the smaller Plated Washer onto the inside of the second bore of the original bracket, this is to ensure the spacing is equal on both sides of the bracket (Figure 2). Once this is done, refit the second original bolt through the bracket.
5. Tension all hardware to manufacturers recommended torque settings, and test drive once fitted.

