

# POWERFLEX®

PART NUMBER

## PFF57-1402

DESCRIPTION

### Front Wishbone Rear Bush

#### INSTALLATION GUIDE

#### Contents (parts per pack):

- 2 x Polyurethane Bushes
- 2 x Mild Steel Shells
- 2 x Stainless Steel Sleeves
- 1 x Powerflex Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

#### Fitting Instructions:

- 1) Remove original bushes from arm.
- 2) Insert shells into front subframe ensuring the lip of the shells is flush to the surface.
- 3) Grease the outside of the polyurethane bushes and insert them into shells.
- 4) Insert sleeves onto wishbone rear pin ensuring the sleeves are flush to the top of the pin.
- 5) Grease inside of polyurethane bushes and insert the sleeves and rear wishbone ensuring a tight fit.
- 6) Reattach arm to car and tension all hardware to manufacturers recommended torque settings.

